

Align the punch so that it is right in the corner of the webbing, but not over the webbing



With a piece of wood underneath and the mat on a solid surface (concrete is preferred), punch a hole through the rubber using a hammer. This can be very difficult because our rubber is industrial grade.



You should end up with a hole like this:



Place the grommet in the installation tool and place on the solid surface



Flip the mat over and align the punched hole with the grommet



You do not need the other half of the grommet.



Use the other half of the installation tool, align and hit it with a hammer.



After a couple of hits it should be flush with the top of the mat.

